

# MEASURING BARCOO STYLE SADDLES

Standard Seat Measurement is to measure from the line of stitching at the pommel to the cantle. Sometimes Internal Seat Measurement is used. Below is a guide:

**15" Saddle = 12½" Internal Seat Measurement**

**16" Saddle = 13½" Internal Seat Measurement**

**17" Saddle = 14½" Internal Seat Measurement**

